














GP041-0077,1











KITCHEN STAND WITH 2 DOORS

INSTRUCTION MANUAL







- 1/3
- A

PS 2X

PI 4X

P5 4X

BP2 2X

BP1 2X

P1 2X

P2 2X

BP4 2X

BP5 2X

P6 4X

P3 2X

P4 2X

P7 2X

- 2/3
- PB 1X

PC 1X

PS 1X

PD 2X

PJ 2X

PY 1X

PS 960x197 mm

PI 960x80 mm

PB 1010x360 mm


PC 960x349 mm

PS 960x349 mm

PD 302x349 mm

PJ 458x296 mm

PY 958x337 mm



NO:H100008 5x50 MM 24 X	NO:P002101 20*20 MM 04 X	NO:H100045 14 MM 14 X	NO:H100006 4x35 YHB MM 12 x	NO:H100023 20 X	NO:H100024 20 X	NO:H100037 Ø8 x 29 MM 16 X	NO:H100001 3,5x50 MM 24 X
NO:H100039 20 X	NO: H100016 04 X	NO:H100002 4x18 YHB MM 18 X	NO: H100186 02 X	NO:H100010 M4x21 MM 02 X	NO:H100190 01 X	NO:P001701 20*20 MM 20 X	NO:H100098 03 X