









GP042-0237,1












A01  34x	A02  18x	A03  12x	A28  35x	A13  6x
A04  A 20x D1 20x D2 6x	A06  8x	E44  3x	E53  KRM 3x	A11  6x
A10  3,5x18 36x	D03  Ø14 6x			




1




2




2x




3




4




5




6




7




8




9




10




11




12




13




14




15




16










1.



2.



to connect the hinge to the door
to arrange the door



arrows to show the directions for arrangement of doors.