



GP042-0271,1
















A01 24x	A02 24x	A04 A 24x	D41 5x70 YHB 4x	D41 Ø8 4x
A41 "L" 4x	A28 28x	A12 DM 4x	A13 13x	A23 R P 16x
A10 3,5x18 YHB 34x	E18 128 MM 2x	A14 M4x22 4x	0x	0x










AUFBAUANLEITUNG / ASSEMBLY MANUAL / MONTAJ KILAVUZU













A= menteşe bağlama vidası / to connect the hinge to the door
B= kapak ayar vidası / to arrange the door




oklar kapağın ayarlama yönünü gösterir.
arrows to show the directions for arrangement of doors.


PART-1




PART-2




PART-3



PART-4



PART-5



PART-6

